Installation Instructions for the Cargo Door Lever Lock

Before installing the Cargo Door Lever Lock be sure the trailer is secured (tires chalked, brakes applied) and will not move.

- 1. Install the Cargo Door Lever Lock by first removing the retaining pin and aligning the lock with the trailer handle as shown. (Figure 1)
- 2. Check the alignment of the keeper holes (where a padlock would normally be inserted) to see that they are aligned and there is a clear path for the retaining pin to be inserted. (Figure 2)
- 3. Install the Cargo Door Lever Lock over the handle and keepers as shown. (Figure 3)
- 4. Insert the retaining pin as shown. (Figure 4) Some alignment may be needed by depressing the handle inward so the retaining pin can slide freely.
- 5. With the keys removed, depress the locking button and store keys in a secure location.

Install additional Equipment Lock devices to secure your trailer.

Removal of the Cargo Door Lever Lock

- 1. Insert key, turn clockwise and lock button will pop out.
- 2. While holding the Cargo Door Lever Lock in position, lift the retaining pin completely out off the Cargo Door Lever Lock body. Some alignment may be needed by depressing the handle inward so the retaining pin can slide freely.
- 3. Remove the Cargo Door Lever Lock from your trailer, re-insert the retaining pin and lock it into place.
- 4. Store the Cargo Door Lever Lock and keys in a secure location.



Figure 1



Figure 2



Figure 3



Figure 4



The Equipment Lock Company Toll Free: 1.866.565.4887 www.equipmentlock.com info@equipmentlock.com